


5 Watt Super Compact UHF CB Fixed Mount Radio with USB Type-C Charging Port EXG1000 USER GUIDE

Radio Installation 1


For full instructions on the EXG1000 radio installation, visit the website for the online user guide.



Quick Release Mounting Bracket (Base Mount):
Install the Quick Release Mounting Bracket to a desired location.




Microphone Hanger (Mic Mount):
Install the Mic Hanger within cable extension range of the Microphone.



Base Connections:
Connect DC power plug to **+12V DC**.
Connect antenna connector to an external **UHF-CB** antenna.

Microphone Connection:
Connect microphone cable to RJ45 jack at the base unit.


Power ON/OFF | Volume 2



Press **and hold** to turn Power On or Off.



When power is turned On the display will temporarily show all segments and then the last channel (default is CH01).



When power is on, rotate to adjust the Volume up or down.

NOTE: The function of the microphone UP and DOWN keys can be changed from Channel up/down (default) to Volume up/down in the MENU.

Selecting a Channel 3



There are three ways to navigate to a channel.



Main Method:
Press **UP** or **DOWN** on the base or microphone to change channel one step at a time.
(Press **and hold** to change channels rapidly.)



One-Touch Shortcut Keys:
Press **PRI** to recall the Priority Channel (Default is CH11).
To store any current channel as the Priority Channel, press **and hold PRI**.



Press **EMG** to recall Emergency Channels 05 and 35.

Channel Usage 4

The EXG1000 has 80 UHF-CB Channels to select from.
Visit the ACMA website for details of citizen band radio usage.

Designated Channels

- Channels **05** and **35** are for Emergency communications only.
- CH.11 Call Channel. Once contact is made, switch to another channel.
- Channels **01-08** and **41-48** are repeater output channels.
Channels **31-38** and **71-78** are the matching repeater input channels.

Limited Use Channels

- CH.22, 23 No voice (talk) is permitted on these channels.
- CH.61, 62, 63 Reserved for future use.

Commonly used for...


- CH.10 4WD Clubs, Convoys & National Parks
 - CH.18 Caravan & Campers, Convoys
 - CH.29 Road Safety (Pacific Hwy NSW-QLD)
 - CH.40 Road Safety (Truckies) Australia Wide
- All other channels are for general use.

CH: 01 02 03 04 **05** 06 07 08 09 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32 33 34 **35** 36 37 38 39 40

CH: 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57 58 59 60 61 62 63 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80

LISTENING: Receive (RX) Basics 5

Setting the Squelch | Signal Strength Indicator



The squelch keeps the radio's speaker muted until a signal stronger than the squelch point is received.

Press the Power knob to open the Squelch setting.

Rotate the Power knob to adjust the squelch point.



There are 9 squelch points available:

- OFF
- 1 high sensitivity (weak signals will un-mute the speaker)
- ...
- 9 low sensitivity (strong signals will un-mute the speaker)



Press the Power knob again to save the new setting.

Adding CTCSS & DCS to the Squelch



CTCSS (CTC) and DCS are Squelch codes. When a Squelch code is set, a signal must have that Squelch code to un-mute the radio's speaker - even if the signal strength is strong enough to pass the squelch point.



Press **MENU** 1 time.
The CTCSS/DCS code setting flashes.
Press **UP** or **DOWN** to select a code from OFF, CTCSS (01-50) or DCS (001-104).
Press **and hold MENU** to set.



NOTE: CTCSS/DCS cannot be set on Emergency channels 05 and 35.

Make sure, when you set a CTCSS or DCS squelch code, to share the code with others you want to communicate with.

Monitor Mode



The Monitor mode bypasses the Squelch, CTCSS and DCS so that you can listen to the open channel. In Monitor mode, RX is on **and flashing**.



Press **and hold MON** to enable Monitor mode.



Press **and hold MON** to disable Monitor mode.

TALKING: Transmit (TX) Basics 6

Always listen on a channel to ensure it is not already being used before transmitting.
To communicate, all radios in your group must be set to the same Channel and, if it is set, the same CTCSS / DCS Code.

To talk, press **and hold** the **PTT** (Push to Talk) key. Hold the radio 5 to 7 cm away from your mouth and speak towards the microphone located just above the display. When you are finished speaking, release **PTT** to listen.

TX and the full signal level will display while PTT is held.


Making Contact Using Call



Call Tone transmits a short tune intended to catch the attention of others on the channel.



To initiate (transmit) the Call Tone:
Press **MENU** ten times.
t-CAL shows on the display.



Push the Power knob.
NOTE: Call Tone can only be used once per minute by regulation.



